



Grow a Better Crop

**Operators
Manual
143J1**

Pasture Renovation Drill



SAFETY

SAFETY FIRST

DO NOT OPERATE THE IMPLEMENT WITH CHAIN DRIVE GUARDS REMOVED

DO NOT ATTEMPT ANY WORK ON THE IMPLEMENT WHILE THE IMPLEMENT IS IN MOTION. (I.E. CLEANING OF BOXES OR LUBRICATION OF DRIVES ETC.)

PRIOR TO WORKING UNDERNEATH THE IMPLEMENT (E.G. CHANGING POINTS ETC.) ALWAYS CHECK THAT THE IMPLEMENT IS ADEQUATELY SUPPORTED ON BLOCKS.



CUSTOMER'S WARRANTY REGISTRATION CARD

(Please retain for your records)

Customer copy

IMPLEMENT TYPE:

IMPLEMENT SIZE:

SELLING DEALER:

SERIAL NO

DATE PURCHASED:

PLEASE READ THE OPERATOR'S MANUAL TO ENSURE CORRECT APPLICATION, OPERATION AND MAINTAINANCE FOR THIS MACHINE.

THANK YOU FOR BUYING JOHN SHEARER

**PLEASE COMPLETE AND RETURN THE WARRANTY CARDS ON
THE FOLLOWING PAGE TO ENSURE WARRANTY IS VALID.
IF THE WARRANTY CARDS ARE NOT CONFIRMED, THE WARRANTY
PERIOD WILL BEGIN ON THE DATE THE MACHINE LEAVES THE FACTORY.**



Dealer copy

WARRANTY REGISTRATION CARD

DEALER NAME: DEALER TOWN:

IMPLEMENT MODEL: SIZE:

PRODUCT No. (As per price book)..... SERIAL NO.

DEALER'S PRE DELIVERY IMPLEMENT CHECK WHEN DONE..... SIGNATURE.....

PURCHASERS NAME (Full).....

ADDRESS (Full).....

DATE OF PURCHASE:.....

PURCHASER ACKNOWLEDGES THAT THE IMPLEMENT WAS RECEIVED IN GOOD ORDER & CONDITION AND THAT PURCHASERS ATTENTION HAS BEEN DRAWN TO THE TERMS AND CONDITIONS OF THE JOHN SHEARER LIMITED WARRANTY POLICY ENDORSED HERE-ON.

PURCHASERS SIGNATURE.....



John Shearer Pty Ltd copy

WARRANTY REGISTRATION CARD

DEALER NAME: DEALER TOWN:

IMPLEMENT MODEL: SIZE:

PRODUCT No. (As per price book)..... SERIAL NO.

DEALER'S PRE DELIVERY IMPLEMENT CHECK WHEN DONE..... SIGNATURE.....

PURCHASERS NAME (Full).....

ADDRESS (Full).....

DATE OF PURCHASE:.....

PURCHASER ACKNOWLEDGES THAT THE IMPLEMENT WAS RECEIVED IN GOOD ORDER & CONDITION AND THAT PURCHASERS ATTENTION HAS BEEN DRAWN TO THE TERMS AND CONDITIONS OF THE JOHN SHEARER LIMITED WARRANTY POLICY ENDORSED HERE-ON.

PURCHASERS SIGNATURE.....

CUSTOMER'S MACHINERY REGISTER



We ask for your assistance in registering your holdings of equipment. This information can assist us greatly in after sales service, development of new products and customer awareness of Shearer products.

1. Name:.....
Address:.....
..... State:..... Postcode:.....
Phone..... E-mail:.....

2. Type of purchaser (please tick) Owner / Manager Share Farmer Contractor

3. Major activities (please number in order of importance)

<input type="checkbox"/> Sheep and cereal grain	<input type="checkbox"/> Vegetables	<input type="checkbox"/> Sugar
<input type="checkbox"/> Sheep only	<input type="checkbox"/> Poultry	<input type="checkbox"/> Tobacco
<input type="checkbox"/> Cereal Grain Only	<input type="checkbox"/> Pigs	<input type="checkbox"/> Oilseeds
<input type="checkbox"/> Meat Cattle	<input type="checkbox"/> Vineyards	<input type="checkbox"/> Others (please list)
<input type="checkbox"/> Milk Cattle	<input type="checkbox"/> Fruit	<input type="checkbox"/>

4. What is the size of your holding (hectares)?.....
What is the total area of your crop (hectares)?.....
What is your area under cereal crop (hectares)?.....

5. In what town is your associated Shearer dealer? (i.e. either the dealer with whom you normally trade or the one who is closest).....

6. What John Shearer machines do you currently have on your property?

Serial No.	Implement type	Size	Date Delivered	Comments

Thank you for your assistance; please feel free to use the back of this form to make any comments you wish.



Congratulations on the purchase of your new JOHN SHEARER PTY LTD implement. You have just joined the growing number of John Shearer customers and we trust that your implement will give you many years of satisfaction. The following information contained in this manual is provided with regards to your implement's operation, maintenance and warranty; however, should you require further assistance, contact your registered John Shearer Dealer.

WARRANTY POLICY

This warranty (**'this Warranty'**) provides information regarding the operation, maintenance and warranty of John Shearer Pty Limited's (**'John Shearer'**) products.

Warranty against Defects

John Shearer warrants to the original purchaser (**'you'** or **'your'**) that any product manufactured by John Shearer (**'Product'**) and sold to you whether directly or through a dealer (**'the Dealer'**) will be free from defects to the extent set out in this Warranty.

John Shearer warrants that any Product or parts of a Product proven to be defective (**'the Defective Product'**) will either be repaired or replaced by John Shearer.

Products will only be proven to be defective by a person appointed by John Shearer. John Shearer holds the discretion to determine whether a Defective Product is to be repaired or replaced.

Any Defective Product must be returned to the Dealer at your cost within 12 months of delivery of the Product to you.

No warranty is given in relation to:

- any Product that has been misused;
- any Product that has been used contrary to its normal and, or intended use;
- any Product that has been used contrary to the recommendations of John Shearer and, or the Dealer;
- any Product that has been altered, modified or had any parts substituted in any way not authorised by John Shearer and, or the Dealer;
- any defect of which you should have reasonably identified by examining the Product or of which you were notified of; and
- general wear and tear during normal use of the Product.

All defects must be reported immediately by you to the Dealer.

Modifications by John Shearer

John Shearer reserves the right at all times to vary, modify and, or improve its Products or parts without notification.

John Shearer has no responsibility to vary, modify and, or improve Products sold to conform with any such modifications.

Freight and Travel Charges

John Shearer accepts no responsibility in relation to:

- travelling and, or freight charges; and

- damage caused during travel and, or freight.

Limitation of Liability

To the fullest extent permitted by law, John Shearer and the Dealer will not be liable for any actions, suits, proceedings, claims, demands, costs, expenses or damages whatsoever which may arise either directly or indirectly in respect of the Product, including but not limited to negligent use of the Product.

To the fullest extent permitted by law, any non-compliance with this Warranty will automatically void any warranty given by John Shearer in relation to the Product. No warranty is given if you have breached any terms and conditions forming part of the contract between you and John Shearer and, or the Dealer by which the Product was sold to you.

John Shearer will not be held responsible for any third party warranties offered in addition to the warranties offered under this Warranty. Any third party warranties are directly between you and the third party offering those warranties.

Consumer Rights

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The warranties given by John Shearer under this Warranty are in addition to your other rights and remedies under the Australian Consumer Law in relation to the Product.

However, to the fullest extent permissible by law, John Shearer does not provide any consumer guarantees which are not required to be given at law.

Service and Maintenance

It is your responsibility to:

- maintain and operate the Product in a safe and correct manner and in accordance with the specifications and operating limitations set out by John Shearer; and
- service the Product regularly in accordance with the recommendations of John Shearer.

Claims

All claims under this Warranty are to be sent to for the attention of Franco Perrotta at John Shearer Pty Ltd. P.O. Box 2466 Regency Park SA 5942

For further assistance, contact the Dealer.

Warranty Provider

This Warranty is provided to you by:

John Shearer Pty Limited
34 Burleigh Ave, Woodville North SA 5012
(08) 8468 4190
info@johnshearer.com.au

02.19M143J1

PRE-DELIVERY CHECK

1. On delivery of PASTURE RENOVATION DRILL ensure there are no shortages.
2. Check Implement equipment, to ensure as ordered.
3. Check for trans-shipping damage.
4. Refer to lubrication section, page 10, for greasing and routine check points.
5. Check and tighten bolts and nuts, (including wheel nuts).
6. Check tyne spacing. For specific dimensions refer to page 27-29 to 31.
7. Ensure that implement is fully assembled and operating correctly.
8. Demonstrate and explain operation to the client.
9. Explain terms and conditions of Warranty to client



JOHN SHEARER

ESTABLISHED 1877
INCORPORATED IN SOUTH AUSTRALIA

PTY LTD

HEAD OFFICE & FACTORY
PO Box 2466 REGENCY PARK
SOUTH AUSTRALIA 5942

TELEPHONE +61 8 8468 4190
STREET LOCATION: 34 BURLEIGH AVE, WOODVILLE NORTH
FAX No. +61 8 8468 4135 (SPARE PARTS)
Website: www.johnshearer.com.au
Spare parts email: spares@johnshearer.com.au

WHEN ORDERING SPARE PARTS PLEASE STATE:

1. **MODEL, SERIAL NUMBER & SIZE (OF THE MACH. / IMP.)**
2. **PART NUMBER AND DESCRIPTION (OF THE SPARE PART).**
3. **NUMBER OF PARTS REQUIRED.**
4. **FORWARDING INSTRUCTIONS.**
5. **CORRECT NAME & ADDRESS OF DESTINATION.**



MODEL & SERIAL NUMBER PLATE
IS PLACED ON THE LEFT HAND FRONT OF THE
MAIN FRAME.

MADE & PRINTED IN AUSTRALIA BY JOHN SHEARER PTY LTD.

M143J1 FEB 2019

CONTENTS

PAGES	DESCRIPTION
3	SPECIFICATION
4-8	SETTING UP / OPERATING INSTRUCTIONS
9	MAINTAINANCE OF "T" BOOTS
10	LUBRICATION
10	TYRE PRESSURES
11	SOWING RATES
12	GRAIN AND FERTILISER CHARTS
14-22	ELECTRIC DRIVE
23	GATE SETTINGS
25-26	TROUBLESHOOTING
27-29	LAYOUTS
30-31	MAIN FRAME, G & F BOX, PLATFORM ETC.
32-33	GRAIN & FERTILIZER SHAFTS, GATES ETC.
34-35	ELECTRIC DRIVE COMPONENTS
36-37	VARIDRIVE
38-39	COIL TYNE ASSEMBLY
40-41	580 TYNE ASSEMBLY
42-43	DISCS AND SCRAPERS ETC. (DISC DRILL)
44-45	TRANSFERS
46-47	HYDRAULICS
48-49	UC300 HECTAREMETER CALIBRATION
50-51	JACKAL CALIBRATION & INFO

SPECIFICATION

No. OF SOWING ROWS:		13	16	19	22
SOWING WIDTH:	m	2.0	2.4	2.8	3.3
	(ft)	6' 6"	8'	9' 6"	11'
SOWING SPACING:	mm	152			
	(in)	(6")			
BOX CAPACITY:					
Rear - Fertilizer	kg	335	403	471	556
	(lb)	739	889	1039	1226
Front - Seed	kg	188	226	265	312
	(lb)	415	498	584	688

COIL TYNE DRILL

Tyne Type		25mm Square Shank Coil Tyne			
Tyne Spacing:		152mm (6")			
Weight Empty	Kg	735	1364	885	1622
(approx.)	(lb)	1620	3007	1952	3577

TYNE DRILL

Tyne Type		"580" Spring Release			
Jump Height		250mm (10")			
Tyne Breakaway Force		16mm diameter spring, adjustable to a maximum 740N (165lbf)			
Tyne Spacing:		152mm (6")			
Weight Empty	Kg	718	1344	861	1594
(approx.)	(lb)	1583	2962	1898	3515

DISC DRILL

Disc Diameter		330mm (13")			
Jump Height		350mm (13 3/4")			
Disc Spacing		152mm (6")			
Weight Empty	Kg	818	1466	1006	1763
(approx.)	(lb)	1802	3232	2219	3886

DEPTH WHEELS 235/75 R15 or 215/85 R16
(depending on size of machine)
Max. working depth 76mm (3")

SEED & FERTILISER DISTRIBUTORS:

Seed - Fluted roller with restrictor for small seeds, low rates
Fertiliser - Nylon Peg tooth distributor roller
Gates - Adjustable rubber in both compartments

DRIVE Electric Drive Standard

OPTIONAL EQUIPMENT

Broad Bean Rollers
Varidrive Gearbox (in lieu of Electric Drive)
Coulter Bar
A wide range of points and fittings

Due to our policy of continuing research, these specifications may change without prior notification.

SETTING UP / OPERATING INSTRUCTIONS

Congratulations on the purchase of your new PASTURE RENOVATION DRILL.

This manual has been prepared to assure the proper set up, operation and trouble free service.

After reading this manual, keep it in the carrier provided on the implement for quick and easy reference should any question arise concerning operation or service.

Your PASTURE RENOVATION DRILL is designed to give maximum service life, but a routine lubrication and maintenance schedule must be followed as shown on the lubrication chart (see page 10)

SETTING UP – TRAILED IMPLEMENT

IMPLEMENT LEVELLING “FRONT TO REAR”.

Adjust hitch link to level implement “front to rear”. Extend the link to increase depth of working of the rear tynes. Set the Disc Drill with the grain and fertilizer box support “level” in the working position.

TURNING

Avoid turning sharply with tynes / discs in the ground. Lift the machine out of the ground at corners and sow headlands separately to avoid oversowing.



SOWING RATES & CALIBRATION

See page 11 for Varidrive Gearbox, 14-22 for Electric Drive

GRAIN AND FERTILISER BOX CAPACITIES

The Grain and Fertilizer box is fitted with distributors, which allow either grain or fertilizer in both compartments. The two compartments of the box are unequal in volume. This feature allows whichever material is being used in higher quantities to be placed in the larger (rear) compartment. The relative volumes are:-

FRONT COMPARTMENT = 45%, REAR COMPARTMENT = 55%
Where both compartments are being used for the same material, optimum use is made of the whole box capacity if the sowing rates selected for each compartment are in the same ratio as the compartment volumes.

$$\text{i.e. } \frac{1.25}{1}$$

For example: If a sowing rate of 100 kg/ha is required, the sowing rates selected for the front compartment should be 45kg/ha and for the rear 55kg/ha. This will provide, as near as possible, simultaneous emptying of both compartments.

DISTRIBUTORS

The peg tooth distributor in the front compartment is suitable for both fertilizer and smaller grains, up to the size of peas and lupins. The fluted distributor in the rear compartment is suitable for fertilizers and grains including pasture and larger seeds. For low rates use the restrictor.

DO NOT USE THE RESTRICTOR WITH FERTILISERS.

NOTE: For broad beans, a special distributor is available. (see page 32-33)

STORAGE

At seasons end, this implement should be stored away, jacked up and placed on blocks to take the weight off the tyres. It should be thoroughly cleaned, removing all traces of seed or fertilizer from compartments and distributors.

Fill gearbox with oil.

Remove chains, clean, lubricate and store in a clean, dry location.

Grease all bearings.

Touch up scratched or damaged paintwork.


FERTILIZER CORROSION DAMAGE

The hopper must be "COMPLETELY AND THOROUGHLY CLEANED OUT" after use, to help prevent corrosion. It is especially important that the hopper is not left overnight with any fertilizer remaining in it. Particular attention should be paid to keeping the area around the critical distributor/bearing/gate components free of fertilizer

This recommendation is applicable irrespective of the kind of fertilizer in use, but is more important with the higher analysis, high nitrogen, fertilizers.

GATE SETTING

The seed and fertilizer metering rollers have an adjustable gate at the metering point under the roller. This adjustment allows for the diversity in size of seed and types of fertilizer. To ensure accurate metering of material, it is essential that these gates be correctly adjusted in accordance with the information supplied below.



Procedure for resetting gates if required:

1. Remove the sowing cups part number 39948.
2. Loosen collar part number 18503 on gate levers and disengage pin part number 18515 from bracket assembly part number 18598.
3. Obtain a spanner to fit the gate shafts. (20mm)
4. With one hand place the gauge between the lip of the gate and the roller.
5. With other hand move the gate shaft using the spanner until the gauge fits nicely between roller and the gate (rather like a feeler gauge)
6. Do not have too tight, otherwise the edge of gate will wear on rollers.
7. When you have the gauge (as selected) in this position, you have gate setting **one (1)**.
8. For placing the pin part number 18515 in position **one (1)** on bracket part number 18598 and tightening socket screw part number 18789 – it is preferable to have the help of another person.
9. Note the gate levers when set in position **one (1)**, are in a different relationship to each other.

GEARBOX SETTINGS (if fitted)

The gearbox can be adjusted to any rate between 0 (no distributor rotation) to 100 percent. The chart on page 12 are a guide to what rate can be expected for various products. Be aware that these chart is a guide only and for accuracy a calibration check must be done before seeding.

TYNE SPRING TENSION

Set tyne spring tensions equally on each row.

Tynes on the front two rows are more likely to need tension. To avoid higher loads than necessary on the tyne assembly components, use the minimum spring tension that will achieve the penetration required.

PASTURE DISC DRILL – SINGLE DISC

PENETRATION OF DISCS


Where you are unable to gain enough penetration with the discs due to hard conditions, more pressure can be obtained by compressing the springs on the pressure rods.

BREAST SET ON DISCS

The set of the disc may be altered by fitting or removing breast adjustment spacers (item 18, page 43) between the arm and the drill boot.

Spacers fitted between the arm and the front hole of the disc boot gives a 50mm set to the disc and to the back hole gives a 70mm set. Spacers taken out altogether give a 60mm set to the disc. Increasing breast angle of disc aids trash or clod clearance, but reduces penetration.

The breast cut of the discs is adjustable to vary the width of the sowing slot.



SAFETY FIRST

DO NOT OPERATE THE IMPLEMENT WITH CHAIN DRIVE GUARDS REMOVED.

DO NOT ATTEMPT ANY WORK ON THE IMPLEMENT WHILE THE IMPLEMENT IS IN MOTION. (I.E. CLEANING OF BOXES OR LUBRICATION OF DRIVES ETC.).

PRIOR TO WORKING UNDERNEATH THE IMPLEMENT (E.G. CHANGING POINTS, ETC.) ALWAYS CHECK THAT THE IMPLEMENT IS ADEQUATELY SUPPORTED ON BLOCKS.



MAINTENANCE OF “T” BOOTS

A tungsten carbide insert has been fitted to the leading edge of the blade

Because the blade is expected to carve a channel through hard abrasive soils, stones and rocks etc., DO NOT DISREGARD NORMAL MAINTENANCE. Continual maintenance of the blade is necessary. The tungsten carbide will slowly wear, but blade surfaces will wear more quickly. Regularly check that all bolts are tight. Ensure that the boot is kept clean of blockages due to buildup of grain or fertilizer so that an unrestricted flow of product is possible.


TENSION ON SPRINGS

The pressure is taken at the bolt that holds the boot on. The correct pressure on tynes is important, the tynes must work on their springs and vibrate to crumble the soil and create tilth over the seed.

3 POINT LINKAGE MACHINES

When using 3-point linkage implements fitted with “T” boots there are guide lines to follow to minimize wear.

- a) When drilling you must sow in a straight line.
- b) If you turn without lifting you will cause excessive wear on sides of blades and sowing tubes.
- c) Lift implement when you come to a corner.
- d) Be in motion when entering ground and lift when stopping.
- e) Do not let implement roll back, if you do, sowing tubes will block with soil forced into opening.



“T” BOOT

LUBRICATION

Item	Operation	Schedule
Wheel Hub	Grease	200hrs
Axle Rockshafts	Grease	Daily / 10hrs
Clutch	Grease	Daily / 10hrs
Tynes	Grease	Daily / 10hrs
Distributor shafts	Grease	50hrs
Trimming Screw	Grease	Annually
Varidrive Gearbox	Check for leaks (topup if necessary- SAE 50W/40 Motor Oil)	Annually
Tyres	Check Pressure	Daily
Chains	Check adjustment	Daily
Chains	Annual Maintenance – thorough check and re-grease	Annually
General Inspection (Nut & Bolts)	Check for tightness	Daily
Hopper	Clean out at end of each day (Particularly Hygroscopic Fertilizer)	Daily
Grease Nipples	Lubricate all prior to storage at the end of each working period	Seasonally

DO NOT LEAVE FERTILISER IN THE IMPLEMENT OVERNIGHT. (PARTICULARLY HYGROSCOPIC FERTILISER, WHICH WILL TAKE UP MOISTURE AND HARDEN)

TYRE PRESSURES

TYRE PRESSURES ARE IMPORTANT								
OVER INFLATION will impair flotation - Increasing sowing depth variations as ground conditions vary.								
UNDER INFLATION can result in tyre failures.								
TYRE SIZE	Pasture Renovation Drill							
	2.0		2.4		2.8		3.3	
	Tyne	Disc	Tyne	Disc	Tyne	Disc	Tyne	Disc
235/75 R15 TYRE PRESSURE kPa	250	275	280	300				
psi	36	40	41	44				
215/85 R16 TYRE PRESSURE kPa					450	480	525	560
psi					65	70	76	81
SPEED LIMIT 25km/h (10km/h SOWING)								

SOWING RATES (Gearbox Option)

Select sowing rates as per chart on the left hand side of the implement. N.B. This chart is to be used as a guide only.

Check sowing rates as follows:

Example: For tyre size 235/75x15 the sowing rate chart is based on an effective wheel rolling radius of 330mm. For a 19 row drill at 155.5mm spacings, 1638 revolutions of the drive wheel corresponds to 1 hectare.

Rotating drive wheel:

1. Lower the machine to engage drive clutch, jack up the left hand drive wheel.
2. Rotate the wheel (anti-clockwise)
 - 49 times – 2.0m (15" wheels)
 - 40 times – 2.4m (15" wheels)
 - 29 times – 2.8m (16" wheels)
 - 25 times – 3.3m (16" wheels)

TYRE	LOADED RADIUS (mm)	WHEEL REVS. /Ha
2.0m 13 Row PASTURE RENOVATION DRILL		
235/75x15	330	2441
2.4m 16 Row PASTURE RENOVATION DRILL		
235/75x15	330	1983
2.8m 19 Row PASTURE RENOVATION DRILL		
215/85x16	374	1474
3.3m 22 Row PASTURE RENOVATION DRILL		
215/85x16	374	1273

tyre/machine size/cranking revolutions

3. Collect and weigh the delivered seed or fertilizer and multiply by 50. This will give the actual sowing rate per hectare for that particular product.
See table below for different configurations of:

Note: the above is based on checking for all rows. If you want to only calibrate using some of the outlets you will need to calculate accordingly.

Equation:

$$\frac{(kg \text{ collected}) \times (\text{Rows on the machine}) \times 50}{(\text{Rows collected from})} = kg/ha$$

example

If you turn the handle 10.5 times and weigh the output collected from 3 rows and it is 0.19 kg (190 grams), then multiply this weight by 19 (for a 19 row drill) and then divide by 3 (for the 3 rows). Since 10.5 turns is equal to 1/50 of a hectare, you need to multiply this by 50 to get the rate per hectare, which is in this example, 60 kg/ha.

$$\frac{(0.19kg) \times (19 \text{ Rows}) \times 50}{(3 \text{ Rows})} = 60 kg/ha$$



**PASTURE RENOVATION DRILL GRAIN & FERTILIZER CHART - Sowing at 152mm spacing.
TO SUIT VARIDRIVE GEARBOX**


46986

Grow a Better Crop


QUANTITIES SHOWN ARE IN KG/HA AND ARE APPROXIMATE ONLY.
CHECK IN FIELD WHEN SOWING COMMENCES

GEARBOX SETTINGS		0	10	20	30	40	50	60	70	80	90	100	GATE SET
GRAN. SUPER PHOS.	NO	0	51	102	152	203	254	305	355	406	457	508	2
HIGH ANAL. FERT.	NO	0	35	71	106	141	177	212	247	282	318	353	2
UREA	NO	0	20	39	59	79	99	118	138	158	178	197	1
WHEAT & PEAS	COARSE	0	7	14	21	27	34	41	48	55	62	68	W, 2.P,3.
	NO	0	30	59	89	118	148	178	207	237	266	296	
OATS & RICE	COARSE	0	4	9	13	17	22	26	31	35	39	44	2
	NO	0	16	33	49	66	82	99	115	132	148	165	
BARLEY	COARSE	0	5	10	14	19	24	29	34	39	43	48	2
	NO	0	20	40	60	79	99	119	139	159	179	198	
LUPIN & SOYBEAN	NO	0	39	79	118	158	197	237	276	316	355	395	3
SORGHUM	FINE	0	4	8	12	16	20	24	27	31	35	39	1
MILLET & CANARY	FINE	0	3	5	8	10	13	15	18	21	23	26	1
SUNFLOWER	NO	0	7	15	22	29	36	44	51	58	66	73	2
LINSEED	NO	0	14	28	41	55	69	83	97	110	124	138	1
LUCERNE & CANOLA	FINE	0	3	7	10	13	17	20	24	27	30	34	1
RYE GRASS	NO	0	7	15	22	29	36	44	51	58	66	73	1
RYE GRASS	COARSE	0	2	4	5	7	9	11	13	15	16	18	1
RYE GRASS	FINE	0	1	3	4	6	7	9	10	12	13	15	1

NO RESTRICTOR




RESTRICTOR




FINE

RESTRICTOR



COARSE

FLUTED ROLLER DISTRIBUTOR



PEG TOOTH ROLLER DISTRIBUTOR



When lower sowing rates are required use restrictor.

Factors are:-

$$\text{COARSE} = \text{UNRESTRICTED} \times 0.25$$

$$\text{FINE} = \text{UNRESTRICTED} \times 0.2$$

Grain or fertilizer can be sown from either the front or rear compartment. If grain or fertilizer is sown from both compartments, the sum of feed rates selected from each compartment should equal total rate required.

This implement delivers similar VOLUME of all materials.

Sowing rates in kg/ha vary in proportion to density (kg/L) of materials.

Sowing rates for unlisted materials may be estimated as follows:-


$$\text{rate for wheat} \times \frac{\text{kg/L (for material)}}{.8 \text{ (kg/L for wheat)}}$$

Setup and Operation


The John Shearer App on the tablet will step you through the setup. Here is a guide to how it works:

Section 1 - Machine Setup


Step 1) press “Configure Machine”



Step 2) enter the number of rows on the machine



Step 3) enter the sowing width of the machine in metres.




Section 2 - Wheel Calibration:

In order to get an accurate measurement of distance and therefore an accurate rate, it is necessary to perform a wheel calibration. This should be performed before the first use of the machine or if a change is made to the wheels on the machine (such as a change in the size of wheels and/or tyres). It is *not* necessary to do this every time the machine is used.


In this process you will need to tow the machine a set number of sensor pulses which will be shown on screen. It is recommended that you perform this test at roughly the same speed as you would normally sow (typically around 8km/h), although it is best to slow down towards the end of the count down, in order to stop accurately at a sensor pulse.

Step 1) Press “Calibrate Wheel Sensor”


Step 2) Mark the starting position of the wheel



Step 3) Move until the sensor is aligned (it will show on screen when ready)




Step 4) Drive until 100 sensor pulses are achieved. The screen will show a countdown.



Step 5) when you have achieved enough pulses, align the sensor again. Then press “Go Next”.




Step 6) Measure and enter the distance travelled.





Section 3 - Seed calibration:

Step 1) Choose your settings

Choose what seeds and/or fertilizer you want to sow first, and what rate (in kg/ha) you want to sow at. The front box (1) usually holds seed, and the rear (2) fertilizer. In “Configure Bins” you can choose these variables and perform a calibration.



The calibration is necessary since not all seeds are the same (for example, wheat from one bag may not be the same as another, due to the size of the grains, moisture content and other factors). The machine remains stationary through this process. The ratio of the drive sprockets is important as it will affect the output. These ratios can be changed to allow for particularly low or high rates to be achieved (see table below). Performing this calibration regularly will help maintain an accurate rate.



On this page select the type of seed or fertilizer to calibrate, the seeding rate and the sprocket ratio (note: the image helps to identify which way the sprockets are positioned).

Step 2) Prepare to collect the seed.

If restrictors need to be added or removed do this now before you fill the box.


Fill the box with the seed you want to calibrate. Make sure there is enough seed to at least complete the calibration. If you are ready to start seeding you may want to fill the bin all the way.

Place a container under the hoses you want to calibrate from (use at least 3 up to as many rows as the machine has – more will be more accurate). The container can be anything large enough to catch the calibrated amount – i.e. a bag, bucket, etc. Make sure it is empty so you aren't calibrating something else as well.

Step 3) Run the Calibration

When the information has been entered, the box is full and you are ready to collect the product, press "Start".

The calibration will run – you will see a countdown on the screen which is equivalent to 100 meters of travel at 10km/h.



Settings being calibrated

Countdown timer

Bin #1 Ideal Gear Ratio is 1 : 3
Seed - Lucern/ Canola - Fine
1 : 2 10.0 Kg/Ha
OK CALIBRATING (2/3) RESTART SKIP

Seeding @ 10 km/h
29 seconds remaining

Bin #1 Ideal Gear Ratio is 1 : 3
Seed - Lucern/ Canola - Fine
Stopped!
Measure weight (expect ~41.8 grams)
50

Enter how much is collected here using the keypad below. If entering less than 1, include the 0 before the decimal point. Press next to enter how many rows it was collected from


Keypad: + 1 2 3 - 4 5 6 . 7 8 9 / * 0 # Next

When the calibration stops, weigh the grain you collected and enter the amount on the screen with how many rows it was collected from.

There is an expected weight shown on the screen with a rough guide to how much you can expect, but the actual value can vary quite a lot. **Make sure that the weight is entered in the correct units after the number of rows has been selected.**

Section 4 – Seeding/Operation:

Step 1) Go to the “Start Seeder” screen – note: when the machine is lifted out of the ground you will see a warning on the screen saying “Tyne Up!” (See below). When you lower the machine into the ground, this warning will disappear and sowing can commence. Ensure the hopper is filled with the calibrated products.




10.4 km/h
0.1 Ha
Shearer

BIN1: Wheat & Pea-Coarse
RATE: 20.0 kg/ha
0.007 kg
Tyne Up!

BIN2: Super
RATE: 117.0 kg/ha
0.038 kg
Tyne Up!

FINISH PAUSE


Step 2) Press the “Start” button on the screen to start sowing. The display will show the distance covered in hectares and the amount of product that has been distributed for each bin in the current run. Seeding will automatically stop when the machine stops (or drops below 3km/h) to conserve product. You can also use the up and down arrows to adjust the rate on the go (in 1kg/ha increments). There is a pause button for each bin to pause only that bin (if you only want to sow seed from Bin 1 for example)



Step 3) Press “Pause” or “Finish” to stop seeding. If you press pause, you can re-start from where you left off.

Note1)

If the incorrect sprocket ratio has been selected for the product, or you are driving too fast (or too slow – for a low speed warning), you may see a warning like this below:




This means that the limits of the motor/s have been exceeded. The solutions could be to either drive slower (or faster for a low speed warning) or to calibrate with a more acceptable sprocket ratio for the selected rate.

The chart on the following page will guide you to an appropriate sprocket ratio.

If seeding continues with this warning, the rate accuracy will be affected.

Note 2)




On machines with bin level sensors, “empty” will show up when a bin is very low or empty. This means it is time to stop and top up the bin.

Continuing with an almost empty bin may lead to the distributor rollers not being able to collect enough seed to maintain an accurate rate.

Records


Tap the View Records button in the main menu.

Records of use are kept for reference. You can add a location such as the paddock where the seeding took place. To do so tap edit and then type a name in the "Enter Location" space.




The record feature will record the products sown, rate, sprocket ratios, hectares covered, start and end time, etc. each time the machine is used.

You can also use a previous record to set the same calibrations.



Note: The records can be removed/deleted if they are no longer required.

Indicator Lights




The secondary box has a number of lights to indicate power, sensor signals and when the Bluetooth link is active with the tablet. These lights can be helpful when testing or troubleshooting.

Circuit breakers

If the motors draw excessive current, either by using incorrect settings or if something is jammed in a roller, the circuit breaker will trip to protect the electronics.

When it trips the button under the clear plastic cover on the end of the metal control box will pop out. To reset a circuit breaker first clear any blockages and simply press the button in.

Circuit breaker



Electric Drive Guideline chart

Note: In most use cases for pasture drills, a 1 : 3 ratio is acceptable.

ratio	1 : 3	1 : 2	1 : 1	2 : 1	3 : 1
Ideal	<p>medium high rate small seeds (such as canola)</p> <p>very low rate medium seeds (wheat, rye)</p>	medium rate small seeds	medium rate medium seeds	very high rate medium seeds	
Acceptable	low rate small seeds (such as canola)	low rate medium seeds	medium rate small seeds	medium rate medium seeds	very high rate medium seeds
Not Recommended	medium high rate medium seeds	<p>medium to high rate medium seeds</p> <p>low or high rate small seeds</p>	<p>high rate medium seeds (especially with no restrictor)</p> <p>any seeds at low rate</p>	low rate medium seeds	<p>small seeds</p> <p>low rate medium seeds</p>

GATE SETTINGS

PRODUCT	GATE SETTING
GRANULAR SUPER PHOSPHATE	2
HIGH ANALYSIS FERT.	2
UREA (granular)	2
WHEAT	2
PEAS	3
OATS	2
RICE	2
BARLEY	2
LUPIN	3
SOYBEAN	3
SORGHUM	1
MILLET	1
CANARY	1
SUNFLOWER	2
LINSEED	1
LUCERNE	1
CANOLA	1
RYE GRASS	1

TROUBLE SHOOTING

PROBLEM	CAUSE	REMEDY
DISTRIBUTORS WILL NOT TURN	Clutch not engaged (if trailing hitch kit fitted) Gearbox not engaged Gearbox shear pins broken Secondary shaft shear pins broken	Check clutch Check gearbox Replace Replace
FERTILIZER RATE VARIES	Fertiliser build-up on distributors	Clean distributor rollers
SOWING DEPTH DIFFERS FROM ONE SIDE OF THE MACHINE TO THE OTHER	Ram lug assembly not adjusted properly Hydraulic cylinders out of phase (if trailing hitch kit fitted)	Check ram lug assembly and adjust if necessary Re-phase cylinders (see page 27)
DISTRIBUTOR ROLLERS DAMAGE SEED	Gate positions are set too close	Re-adjust gate settings
IMPLEMENT KEEPS DROPPING SEED AND FERTILIZER WHEN IN THE TRANSPORT POSITION	Gate settings too wide Gate settings in cleaning out position	Re-adjust gates to recommended setting
SOWING RATE UNEVEN ACROSS GRAIN AND FERTILIZER BOX	Gate setting is unequal across box	Re-adjust gates to recommended setting

TROUBLESHOOTING - PHASING HYDRAULIC CYLINDERS

[Note: the numbers in brackets below refer to the item numbers on the hydraulics part pages (page 58 & 59)]

The two cylinders are connected in series, such that each moves together to provide a level lift of the implement.

When the implement is RAISED, oil delivered from the tractor is directed to the piston end of the master cylinder (5), oil from the rod end flows to the piston end of the next cylinder (4), and oil from the rod end of (4) flows back to tractor. The volumes of the cylinders are matched so that both cylinders extend and retract simultaneously.

To ensure that all cylinders begin work “in phase”, each cylinder has a “phasing bypass” hole in the barrel that allows a small volume of oil to pass across the piston when the cylinder is fully extended (implement fully raised).

To achieve levelling of the implement (initially, or after storage, or as a result of one cylinder having an imperfect piston seal) the implement should be:

- Fully raised,
- The tractor control valve be held in the raise position with the tractor at idle (it may require holding the valve for several minutes to fully purge the system),
- All cylinders be viewed separately to ensure that they have reached full extension (cylinder travel has ceased),
- The tractor valve is then released and the implement can be lowered, levelled with the levelling screw assembly on the hitch, or transported, as required.


Should a leaking piston seal be suspected, identify cylinder by:

- Phasing the implement as above,
- Lower implement slightly, but with tynes still clear of the ground,
- Close the needle valve (16) to ensure no flow back to tractor,
- Measure the shiny rod extending from each of the cylinders,
- Leave the implement stand long enough to be able to measure any change in the dimensions measured (overnight, and not in direct sunshine is preferable).


The first cylinder in the series, that has “dropped” is at fault. If only one has “dropped”, it is at fault. If both have “dropped”, the “master cylinder” (5) is at fault

This of course assumes no external leakages from any of the cylinders, or their connecting plumbing.


580 TYNE LAYOUT – 2.8m




COIL TYNE LAYOUT – 2.4m



DISC LAYOUT




MAIN FRAME, GRAIN AND FERTILIZER BOX, PLATFORM ETC.




MAIN FRAME, GRAIN AND FERTILIZER BOX, PLATFORM ETC.

ITEM	PART No	DESCRIPTION	ITEM	PART No	DESCRIPTION
1	45889	FRAME ASSEMBLY – 3.3m			
	46888	FRAME ASSEMBLY – 2.8m			
	46887	FRAME ASSEMBLY – 2.4m			
	46886	FRAME ASSEMBLY – 2.0m			
2	46575	HOPPER ASSY CPT (ELECTRIC DRIVE) – 3.3m / 22R			
	46574	HOPPER ASSY CPT (ELECTRIC DRIVE) – 2.8m / 19R			
	46573	HOPPER ASSY CPT (ELECTRIC DRIVE) – 2.4m / 16R			
	46572	HOPPER ASSY CPT (ELECTRIC DRIVE) – 2.0m / 13R			
	47167	HOPPER ASSY CPT (ELECTRIC DRIVE) – 2.8m / 22R			
	47166	HOPPER ASSY CPT (ELECTRIC DRIVE) – 2.4m / 19R			
	47165	HOPPER ASSY CPT (ELECTRIC DRIVE) – 2.0m / 16R			
	46870	HOPPER ASSY CPT (GEARBOX) – 3.3m / 22R			
	46869	HOPPER ASSY CPT (GEARBOX) – 2.8m / 19R			
	46868	HOPPER ASSY CPT (GEARBOX) – 2.4m / 16R			
	46867	HOPPER ASSY CPT (GEARBOX) – 2.0m / 13R			
	47164	HOPPER ASSY CPT (GEARBOX) – 2.8m / 22R			
	47163	HOPPER ASSY CPT (GEARBOX) – 2.4m / 19R			
	47162	HOPPER ASSY CPT (GEARBOX) – 2.0m / 16R			
3	46790	HANDRAIL ASSEMBLY – 3.3m			
	46789	HANDRAIL ASSEMBLY – 2.4 & 2.8m			
	46787	HANDRAIL ASSEMBLY – 2.0m			
4	46806	PLANK, PLATFORM – 3.3m			
	46805	PLANK, PLATFORM – 2.8m			
	46804	PLANK, PLATFORM – 2.4m			
	46803	PLANK, PLATFORM – 2.0m			





ELECTRIC DRIVE COMPONENTS



ELECTRIC DRIVE COMPONENTS



ITEM	Part No	DESCRIPTION	QTY.	ITEM	Part No	DESCRIPTION	QTY.
1	44977	MOTOR ASSEMBLY	2				
2	46445	BOX, MAIN CONTROL	1				
3	46446	BOX ASSY, SPLITTER	1				
4	45927	SHAFT, MOTOR	2				
5	18021	Hex Nut, M16 Gr8	2				
6	46013	SENSOR, BIN LEVEL	2				
7	44975	SENSOR, HALL EFFECT	2				
8	46359	MAGNET	3				
9	46874	SPROCKET, 10T	2				
	46873	SPROCKET, 15T	4				
	46859	SPROCKET ASSY, 30T	2				
		USE SPROCKETS IN COMBINATION FOR APPROPRIATE RATIO, i.e. 1 : 3 or 3 : 1 (10T & 30T) 1 : 2 or 2 : 1 (15T & 30T) 1 : 1 (15T & 15T)					

VARIDRIVE GEARBOX




VARIDRIVE GEARBOX

ITEM	Part No	DESCRIPTION	QTY.	ITEM	Part No	DESCRIPTION	QTY.
1	46953	DRIVE UNIT ASSEMBLY	1				
2	46954	SPROCKET, 14T	1				
3	18802	SPROCKET ASSY, 15T	2				
4	46955	SPROCKET, 13T	2				
5	46594	HANDLE ASSEMBLY, ADJUSTMENT	2				
6	43984	KNOB, M12	2				
7	46956	GUARD - VARIDRIVE/PRD	1				
ITEM 1 MADE OF:							
8	46931	MOUNT ASSY, DRIVE ARM	1				
9	46930	DRIVE WHEEL ARM ASSY	1				
10	46932	EXTENDED DOUBLE SPROCKET	1				
11	46933	AXLE ASSY, DRIVE WHEEL	1				
12	800-055	SPRING FOR PRESSURE ARM	1				
13	11951	SEAT FOR TYNE SPRING NI HARD	1				
14	13407	EYEBOLT M16 - STRAIGHT	1				
15	46935	SPROCKET, 19T	1				
16	11952	CAP FOR TYNE SPRING	1				
17	37414	BEARING 6005LLU	2				
18	18084	M16 x 100-N	1				
19	17605J1	M20 x 90	1				
20	17775J1	M10 x 45	4				
21	18021	NUT, HEX - M16	2				
22	18675	CIRCLIP, SHAFT - 25mm EXT	1				
23	37098	BUSH, ARM JUMPER	2				
24	18534	WASHER, CLUTCH	1				
25	18661	PIN, SELLOCK-5x45mm	1				
26	46934	WHEEL, DRIVE	1				
27	31993	NUT, NYLOC M10	4				
28	FBW4	WASHER, FLAT - 10mm	4				



COIL TYNE ASSEMBLY

ITEM	PART No	DESCRIPTION	QTY	ITEM	PART No	DESCRIPTION	QTY
1	23674	TYNE, COIL - L/H					
	23675	TYNE, COIL - R/H					
2	18985N	BRACKET FOR BAKER BOOT					
3	989-881	POINT, BAKER					
4	19635	CLAMP, TOP TYNE CAST					
5	46821	CLAMP ASSY, COIL TYNE					
6	46825	PLATE, CLAMP					
7	22998	BOLT, HEX - M12 x 65					
8	18124	BOLT, HEX - M20 x 140					
9	46915	BOLT, HEX - M20 x 160					
10	22026	NUT, HEX - M20					
11	38533	NUT, HEX - M12					
12	FBW10	WASHER, FLAT - 20mm					
13	FBW6	WASHER, FLAT - 12mm					




580 TYNE ASSEMBLY

ITEM	PART No	DESCRIPTION	QTY	ITEM	PART No	DESCRIPTION	QTY
1	22902	TYNE & SPRING ROD ASSEMBLY					
2	22927	SPRING, 16mm					
3	22926	CUP, SPRING					
4	22026	AS 1112.1 S1 - M20-D-N					
5	22931	PIN ASSEMBLY, TYNE CRANKED					
6	36949	CARRIER ASSY, TYNE (100SQ)					
7	34527	CLAMP, TOP SQ MOUNT					
8	28912	AS 1112.1 S1 - M16-W-N					
		ITEM 1 (22902) IS MADE UP OF					
	22913	ROD, SPRING EOT (580)					
	22904	TYNE ASSY, 580 EOT					
	21612	BUSH					
	18813	PIN, SPRING ROD					
	18596	NIPPLE, GREASE - SELF TAPPED					
					36952	COMPLETE ASSEMBLY (ITEMS1-8)	

DISC ASSEMBLY

DISCS & SCRAPERS



DISC ASSEMBLY

ITEM	PART No	DESCRIPTION	QTY	ITEM	PART No	DESCRIPTION	QTY
1	42256	DISC ARM ASSY.		31	34084	SPINDLE Bearing	
2	36949	CARRIER ASSY. Tyne		32	34085	COLLAR Seal	
3	22913	ROD ASSY. Spring E.O.T.		33	29751	BEARING Ball – deep	
4	18813	PIN Spring rod		34	29843	'O' RING	
5	22927	SPRING		35	10341	CAGE Bearing	
6	22926	CUP Spring		36	FHR2	RIVET Flat hd. $\varnothing\frac{1}{4}$ " x $\frac{1}{2}$ "	
7	18312	WASHER Flat, \varnothing 20 black		37	33105	HOSE ASSY. convoluted	
8	22026	NUT Nyloc M20					
9	21612	BUSH Tyne					
10	22931	PIN ASSY. Tyne - cranked					
11	17776J1	WASHER Spring \varnothing 10 plated					
12	17777J1	NUT Hex M10 Gr 8.8 plated					
13	18824	BOLT Hex M10 x 30 plain					
14	34527	CLAMP Top - tyne					
15	17606J1	WASHER Spring \varnothing 16 plated			10368	BOOT / SCRAPER ASSY. R.H. Items 23, 24 & 26	
16	18021	NUT Hex M16					
17	18596	NIPPLE grease					
18	490	SPACER Breast adjustment			10648	BOOT / SCRAPER ASSY. L.H. Items 23, 25 & 27	
19	33099	BOLT Cup hd. Sq. M12 x 50					
20	33098	BOLT Cup hd. Sq. M12 x 65 (ext. d/bar)					
21	26892	BOLT Cup hd. Sq. M12 x 45 (ext. d/bar)			10367	DISC / BEARING ASSY. Items 30-36	
22	HR115	BOLT Hex 5/8" BSW x 2-1/4"					
23	31242	BOLT Hex M6 x 30 Gr 8.8 (1 off)					
	18659	BOLT Hex M6 x 25 Gr 8.8 (2 off)			10369	BOOT & DISC ASSY. R.H. Items 22-24, 26, 28-36	
	18656	NUT Hex M6					
	18504	WASHER Spring 6mm					
24	99-9	SCRAPER Disc R.H.			10649	BOOT & DISC ASSY. L.H. Items 22, 23, 25, 27-36	
25	99-10	SCRAPER Disc L.H.					
26	10338	BOOT R.H.					
27	10647	BOOT L.H.			11594	BEARING & CAGE ASSY. Items 31-35	
28	10364	WASHER Shim 26g					
29	12348	SEAL Ballrace					
30	240-1008	DISC \varnothing 13" x 9/32" (10342)					
31	34084	SPINDLE Bearing			42284	DISC ASSEMBLY, COMPLETE – R/H Items 1-24, 26, 28-37	
32	34085	COLLAR Seal					
33	29751	BEARING Ball – deep					
34	29843	'O' RING			42283	DISC ASSEMBLY, COMPLETE – L/H Items 1-23, 25, 27-37	
35	10341	CAGE Bearing					
36	FHR2	RIVET Flat hd. $\varnothing\frac{1}{4}$ " x $\frac{1}{2}$ "					
37	33105	HOSE ASSY. convoluted					

TRANSFERS



JOHN SHEARER

johnshearer.com.au

WARNING !!
SAFETY STOPS MUST BE FITTED TO HYDRAULIC CYLINDERS FOR TRANSPORT AND MAINTAINANCE

3 Pasture Renovation Drill

4


GATE SETTINGS	
PRODUCT	GATE SETTING
GRANULAR SUPER PHOSPHATE	2
HIGH ANALYSIS FERT	2
UREA (granular)	2
WHEAT	2
PEAS	3
OATS	2
RICE	2
BARLEY	2
LUPIN	3
SOYBEAN	3
GORGHUM	1
MILLET	1
CANARY	1
SUNFLOWER	2
LINSEED	1
LUCERNE	1
CANOLA	1
RYE GRASS	1

5

TYRE PRESSURES ARE IMPORTANT
OVER INFLATION = 4 times faster wear
Increasing sowing depth variations as ground conditions vary.
UNDER INFLATION can result in tyre failure.


TYRE SIZE	10 ROW		12 ROW		15 ROW	
	TYRE	DDO	TYRE	DDO	TYRE	DDO
235/75 R15	207	276	207	276	224	276
TYRE PRESSURE kPa	30	40	30	40	34	38
12.50-15.5	155	200	155	200	160	200
TYRE PRESSURE kPa	22	28	22	28	25	28
PSI	3	4	3	4	3.5	4

SPEED LIMIT 25 km/h (15 with SOYBEAN)



7 sling here

9 **WARNING**
DO NOT CARRY BAGS OF GRAIN AND FERTILIZER ON LOADING PLATFORM




13 **DANGER**
DO NOT RIDE ON THIS IMPLEMENT



15 **DANGER** LOWER IMPLEMENT ONTO TYNES BEFORE UNHITCHING TRACTOR

16 **WARNING**
MAXIMUM TOWING SPEED 25 km/h




TRANSFERS

ITEM	PART No	DESCRIPTION
1	46263	TRANSFER John Shearer trademark
2	15875J2	TRANSFER John Shearer
3	46610	TRANSFER Pasture Renovation Drill
4	46984	TRANSFER Gate Settings
5	46985	TRANSFER Tyre pressures
6	28851	TRANSFER Gate setting levers
7	15854J1	TRANSFER Sling here
8	15968J1	PLATE J.S. model & serial no.
	16161J1	SCREW Drive 5/16" x 0.116 x 4U
9	15953J1	TRANSFER Warning do not carry bags
10	27463	TRANSFER Grease 10 hrs
11	27464	TRANSFER Grease 50 hrs
12	27409	TRANSFER Grease 200 hrs
13	22699	TRANSFER Do not ride on implement
14	15880J1	TRANSFER Protect your equipment
15	34732	TRANSFER Lower onto tynes before disconnecting
16	18949	TRANSFER Maximum towing speed
17	43539	TRANSFER Safety Stops must be fitted
18	46957	TRANSFER Gauge 0-100 (Gearbox models only)
19	46958	TRANSFER Gauge 100-0 (Gearbox models only)
20		TRANSFER Chart (Gearbox models only)
21	21532	KIT – CARRIER PARTS MANUAL ⇒ Items 22 – 24
22	43313	TUBE Carrier parts manual
23	20809	TRANSFER Parts manual
24	18502	SETSCREW Hex M8 x 16
	FBW3	WASHER Flat Ø5/16"
	18464	NUT Hex M8




HITCH KIT / HYDRAULICS



HITCH KIT / HYDRAULICS

ITEM	PART No	DESCRIPTION	QTY
1	46000	HITCH ASSEMBLY	1
2	46687	TOP LINK	1
3	46566	ARM AND WHEEL ASSY (LH) – 16"	1
	46813	ARM AND WHEEL ASSY (LH) – 15"	1
4	46565	ARM AND WHEEL ASSY (RH) – 16"	1
	46812	ARM AND WHEEL ASSY (RH) – 15"	1
5	44133	3.75x8" HYD CYLINDER	1
6	44132	3.5 x 8 HYD. CYLINDER	1
7	34528	BLOCK, BEARING - OUTER	4
8	46507	PIN, TOP	3
9	22889	LYNCH PIN	10
10	17887J1	AS 1110.2 - M16 x 60 -N	16
11	28912	AS 1112.1 S1 - M16-W-N	16
12	800-015/2	PIN 26x122	1
13	43618	PIN, HITCH BOTTOM CAT2	2
14		HOSE, HYD. - 3/8" (MAIN)	1
15		HOSE, HYD. - 3/8" (RETURN)	1
16		HOSE, HYD. - 3/8" (ACROSS)	1
FOR LINKAGE MACHINES IN PLACE OF RAMS:			
17	46960	BAR, TELESCOPIC-OUTER ASSY	2
18	46959	BAR, TELESCOPIC-INNER ASSY	2
19	27018	PIN, CLEVIS	2

For linkage machines a telescopic link is included in place of hydraulic rams. The purpose of these is to adjust the digging depth of the tynes or discs in relation to the wheel. These have up to 9 settings in total. For machines with 16 inch wheels, the first 6 settings are applicable. For machines with 15 inch wheels use settings 4 to 9. The factory setting is shown as shaded.




UC 300 Hectaremeter (P/N: 44430) Calibration

(for Gearbox Models)


Programming

Step 1 –hold down the programming button for 3 seconds until the screen shows with Un 0 as shown below. This means that the system will be using the metric system. If you are looking to use the imperial system simply press the + arrow so the display shows UN 1. When happy with either metric or imperial press the programming button once



Step 2 – For the next step the display should read C with some numbers followed after it. The C represents the amount of pulses emitted by the speed sensor after each 100 linear meters. The default value for this function is 200 as shown below. If unsure of the value you need for your machine simply press the + and – buttons simultaneously to get the screen to read out C 0 as shown below. Once the screen reads out C 0 simply run your machine for 100 meters and the value displayed

should automatically go up accordingly. After you have found the automated value, press Program again to move onto the next step.



Step 3 – for the final step the screen should have L displayed. L is the working width of your machine so simply input the width of the machine into the display using either the + or – button. (if the buttons are held down the displayed figures move faster in the given direction). Finally hit Program to save all the inputted settings.



Use Modes

The units displayed is chosen in programming. Please read above to find out how to change from metric to imperial or vice versa.

<p>The digital display shows '0.108' with 'ha' above it. Below the display are five icons: a hatched square, a white square, a tractor, a combine harvester, and a sand timer.</p>	<p>The first figure is the total counter it is the counter used to find out how many hectares have been done in a season, weekly or whatever else you would like to count as a total number.</p>
<p>The digital display shows '0.099' with 'ha' above it. Below the display are five icons: a hatched square, a white square, a tractor, a combine harvester, and a sand timer.</p>	<p>The second picture is the partial counter which gets reset now and again. It is used more for counting things such as how many hectares have been covered in a day or how many hectares there are in each paddock</p>
<p>The digital display shows '0.0' with 'km/h' above it. Below the display are five icons: a hatched square, a white square, a tractor, a combine harvester, and a sand timer.</p>	<p>The third picture shows you how fast you are going in km/h.</p>

<p>The digital display shows '335' with 'm' above it. Below the display are five icons: a hatched square, a white square, a tractor, a combine harvester, and a sand timer.</p>	<p>The fourth figure tells you how much distance has been covered by the machine</p>
<p>The digital display shows '0.0' with 'h' above it. Below the display are five icons: a hatched square, a white square, a tractor, a combine harvester, and a sand timer.</p>	<p>The fifth and final figure is the working hours covered which tells you how many hours you have worked</p>

(Each figure must be reset individually by holding the reset button for a few seconds until the figure goes blank)


OPTIONAL JACKAL (P/N: 42978) CALIBRATION

1. Press the MENU key until the input the sensor used for calculating rate information is connected to is displayed (input 1 – 6).
2. Press ENTER to edit the input function and use the NAV keys to select the **SPEED** option as shown in Figure 13 below.



Figure 13.

3. Select **SPEED** setting with desired Units.
 - **DO NOT MIX METRIC AND IMPERIAL UNITS.**
4. Clear **PULSES** by holding CLEAR for approximately 1 second.
5. Ensure Jackal is in **RUN** mode (when in **HOLD** mode “ON HOLD” is displayed at the top of the screen)
6. Drive a known distance. Jackal should count **pulses**.
7. Enter distance into monitor using NAV keys and hold SET for approximately 1 second to calculate **WHEEL** factor.
8. Enter the Implement **WIDTH** using the NAV keys.



Note: These steps refer to SET and CLEAR buttons. They are activated by the softkeys which will have the words on the screen above the button (as shown in figure 13 above), when in the correct menu.

For more information refer to the Farmscan Jackal manual.

Jackal - Grain & Fertilizer Shaft Monitoring

The distributor shafts have a magnet embedded in them which together with a sensor can be used to monitor shaft rotations. An alarm can be set to warn you if the shaft speed drops below a certain amount (see section 3.2.1.2 of the Farmscan Jackal Manual). We suggest setting a low figure so that the alarm will give a warning if the shaft stops turning for some reason when seeding.

The shaft sensors, as well as the standard area sensor can be connected to inputs B1-6 with the white wire (note: if you expect to use a coil sensor, do not use port B1). The black ground wire for each sensor all connect to port A1. See section 6.3.1 of the Jackal Manual for more information.

The sensors will need to be calibrated on the Jackal monitor as shown in section 4 of the Jackal Manual (note: these are 'Digital inputs').

